



Instructions For the Fastime 18 Stopwatch: 1/1000th sec 30 lap memory, Repeating countdown timer, pacer, alarm and time of day functions

Stopwatch mode:

| | | |
|----------|----------|----------|
| A | B | C |
|----------|----------|----------|

Event Timing:

Press **C** – Start, **C** – Stop (time Out) **C** – Continue
C – Stop **A** - Reset

Split Timing:

Triple display:

Top display shows cumulative split time
Middle display shows last lap split time
Bottom display is cumulative running time

C –Start, **A** – Split, **C** – Stop, **A** – Reset.



Memory Recall: Press **B** anytime to recall memory.

Press **B** each split time to show split times starting from the first split. Each display shows the split number, the lap time and cumulative time.

Press **C** to show the average lap time

Press **A** to show the fastest/slowest lap times

Press **MODE** to return to current running time

Press **MODE** button to move to Repeating Countdown Timer (9hr 59m 59sec) display:

To set timer, Press and hold **A** until digits flash. Press **A** to choose digits to change. Press **C** to change the digits. Press **MODE** to exit setting.

To start/stop the timer press **C**

Display shows target time, countdown time and number of repeats

Press **MODE** button to move to Pacer display:

Press **A** to set the pacer (from 10 to 240 per minute). Press **C** to start/stop the pacer
The display shows the pace per minute and the number of paces elapsed

Press **MODE** button to move to Time of Day/date display:

To set time of day and date, Press and hold **A** until digits flash. Press **A** to choose digits to change. Press **C** to change the digits. Press **MODE** to exit setting

Press **MODE** button to move to Alarm /Date display:

To set alarm time, Press and hold **A** until digits flash. Press **A** to choose digits to change. Press **C** to change the digits. Press **MODE** to exit setting

